

Outside

Page 1

Page 3




Tango

To turn the device on/off:
•5 rapid clicks

To Pre-Heat battery:
•2 rapid clicks

Variable Voltage Battery:
•To change between settings 3 rapid clicks
•Green: 2.7v
•Blue: 3.2v
•Red: 3.6v



Specification:

- Size: 42x65x14mm
- Battery Capacity: 650mAh
- Standard 510 Thread accepted
- Standard Pods accepted
- Micro USB Charger

DO NOT USE WHILE CHARGING!

Randys offers 2 types of warranty on all of our vaporizers!

Limited Warranty - 1 Year

Covers defects that may be present such as electrical components.

Limited Component Part Warranty - 1 Year

Covers damages involving glass, coils and/or mouthpieces.

Visit: Randys.com/warranty for more info!



Inside

Page 2

Page 4



Tango

Thank you for picking up the Randy's Tango. The Tango combines two devices into one, a cartridge battery and a pod battery. We hope you enjoy your new device because it takes two to Tango.

Warnings:

- Always turn the device off when not in use.
- Components may become hot, use caution when handling the device after use.
- Only use the included charger to charge the device.
- Do not leave this device unattended while charging.

When you have both a cartridge & pod in the Tango at the same time, it will only deliver power to the cartridge.

NEVER HEAT UP A DRY ATOMIZER

Usage:

- Screw the magnetic connector to your cartridge.
- 5 clicks to turn the device on
- 3 clicks to select your voltage level
- Press the activation button while inhaling
- Repeat as desired.

Charging:

When the Tango is charging, a red LED will flash to indicate that is charging.

The Light will turn green once the device has become fully charged.

If you need replacement parts visit the shop you purchased the Tango or you can shop Randys.com!