

Manuals for Randy's 650mAh, 1100mAh, 1600mAh Twist Batteries

Since 1975

Randy's[®]

Operations

Activate Battery - Press hold
Blue LED

Turn on/off - 5 clicks
Purple LED

Preheat 12s - 2 clicks
Red/Purple/Blue LED Sequence

Change Mode - Twist bottom



Activation Button
Voltage Selection

Voltage Range:

2.8V - 4.0V

90 Day Limited Warranty
For more info please visit
Randys.com

Charging

Insert the USB Charger into the Charging port. There will be a light that stays on while charging. Once fully charged, the light will turn off.

Warnings:

Do not use while charging

Do not leave unattended while charging device

Only use the included charger

Turn off the device when not in use

Caution, device may be hot after use

Connect with our Social Media



@Randyspapers



@Randyswired



@Randyswired



@Randyswired