







g @randyswired

KIT INCLUDES/OPERATING

- Zipp Vaporizer
- Charging Cable/Wall Adapter
- → Packing Tool & Cleaning Brush
- → 3 Protective Silicone Mouth Guard
- ◆ 5 Mesh Screens

Thank you for purchasing a Randy's Zipp! This is an advanced OLED display aromatherapy device with temperature control (350°F-430°F) for vaporizing herbs. The Ceramic Heating Chamber and Mouthpiece make the vaporizing process exceptional and facilitate the desired effect by baking, rather than combusting.

Combustion can instantly destroy the key elements found in various herbs and can release a multitude of undesired chemical compounds. We hope you enjoy the quality and performance of your new Zipp Vaporizer!

REMOVING MOUTHPIECE / CHARGING







IMPORTANT: Always allow mouthpiece to cool down before removing.

To Charge Zipp:

- Plug the included USB charger into the wall adapter.
- Plug the Micro USB into the Device. An LED indication will confirm charging.
- ➤ A Blue LED will begin to slowly flash while charging and will turn solid blue when the device is fully charged.

MPORTANT: When you first purchase the Zipp, charge it for 3 to 4 hours. After this, do not charge the Zipp for longer than 2 hours. Charging the battery for more than 2 hours at a time may lead to drop off of battery longevity and performance. Do not leave the device unattended while charging. Only use the included charger for your device

CONNECT WITH OUR SOCIALS











LIMITED WARRANTY INFO

The Randy's Zipp comes with a 1 year limited warranty on the device known as a standard warranty. This includes defects that might be present in the body and electronic parts.

We also offer a limited component part warranty on glass components, coils and/or mouthpieces.

For component part warranty claims involving glass, coils, or mouthpieces there is a shipping and processing fee of \$9.99 per claim for continental US orders and \$16.50 per claim for non-continental US and international orders. Please email Sales@Randys.com for more information about warranty claims on glass, coils and mouthpieces. Please include your proof of purchase, proof of legal age and a short description of your issue and the product you are inquiring about.

The Randy's limited warranty is limited to a maximum of 2 replacements on any given purchase of a device. The item must be defective (i.e. this is not an exchange or refund system), and will be replaced with an equal item from current inventory. The limited warranty does not apply to product lines that have been discontinued by Randy's. The defective item must be returned to Randy's per the instructions on the next page.

The details listed above are subject to change without warning and/or notice.

Cover Page 2 Page 4 Page 6 Page 6

INTRODUCTION

Thank you for purchasing the Randy's Zipp! Please read and follow the instructions carefully. Understand them fully before your first use. It is recommended that these instructions are put into a safe place for future reference. We hope you enjoy the quality and performance of your new Zipp vaporizer.

You must be over 18 years old (21 in some states) to purchase and use the Randy's Zipp. This product should not be used by children, women who are pregnant or breastfeeding, or those with life threating illnesses without first consulting a doctor!

Randy's Zipp is not a medical device and is not intended to diagnose, cure, treat, or prevent any diseases or other conditions. If you have any health problems, consult your doctor before using. Randy's Zipp is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties and/or imprisonment under law of your jurisdiction.

SPECIFICATIONS / CHARGING

Battery Capacity: 2200mAh

Charging Voltage/Current: 5V/500mAh

Working Voltage: 4V

Pen Size: 5.11 in x 1 in

Resistance: 1.00hm

Charging Time: 1-2 hours

Temp Range: 350°F - 430°F

Button Controls:

To Turn on/off: Press the button 5 times.

Increase temp: Press (+) for each

degree you would like to decrease

Decrease temp: Press (-) for

each degree you would like to decrease by.



OPERATING INSTRUCTIONS

The Zipp comes with 80 temperature settings: 350°F - 430°F

- **Step 1:** Carefully remove Mouthpiece.
- Step 2: Gently pack ground material into the Zipp baking chamber.
- Step 3: 5 clicks to turn the battery on.
- Step 4: Select Temp Setting The temp. wil increase/decrease 1 degree each time the +/- button is pushed.

350°F - LOW

380°F - MEDIUM

430°F - HIGH

Step 5: Wait for the device to heat up. The LED screen will indicate when the device is fully to temp.

Step 6: Once the device is to temperature inhale slowly.

Warnings:

- Vaporizer may be hot after use. Be cautious when touching the device after use.
- Turn off the vaporizer when not in use!

No vapor being produced:

- 1. Ensure device is turned on.
- 2. Make sure your battery is charged.

TROUBLESHOOTING

Regular maintenance and cleaning of your Zipp is highly recommended.

Do not use the Zipp if the walls/mouthpiece become chipped, cracked, or broken.

If you lose any part or need a replacement, visit the shop where you purchased the device or you can shop Randys.com.

NEED A DEEPER CHAMBER? CHECK OUT THE RANDY'S TROO



3 PRESET TEMP SETTINGS!

WARRANTY CLAIM INSTRUCTIONS

To file a claim online:

Randys.com/warranty **Email: Sales@Randys.com**

We can not replace any unit or part without a proof of purchase. Warranty claims usually take 2-3 weeks to process.

Please Return to: Randy's Warranty

P.O. Box 1253 Holland, OH 43528 The Randy's Zipp has a one year warranty from date of purchase. Defective part must be returned within 365 days of receipt date.

Send us:

1. The defective part

(Please only send parts that are defective and clean)

- 2. A copy of your proof of purchase
- 3. A copy of proof of legal age
- 4. A note detailing the issue(s)
- 5. Return address

We do not warranty the product or any part of the product from careless damage such as dropping the unit or damaged mouth pieces. The Warranty does not cover coils or any glass components. Due to usage, the coils will need replaced on occasion.

Page 1 Page 3 Page 5 Page 7 Page 7